


MAINTENANCE INSTRUCTIONS
SECTION D'ENTRETIEN
WARTUNG
SEZIONE DI MANUTENZIONE
INSTRUCCIONES DE MANTENIMIENTO
ONDERHOUD



(TPD 2001-0)

PART NUMBER FOR ORDERING
REFERENCE POUR COMMANDE DE LA PIECE
BESTELNUMBER
NUMERO DEL PEZZO PER L'ORDINAZIONE
SIMBOLO DE LA PIEZA PARA PEDIDOS
BESTELNUMBERS

	1	Cylinder	2131-3A	+	14	Hammer (2)	2131A-724
	2	Front End Plate	2131-11		15	Hammer Case Assembly . . .	AW5000-727
◆	3	Rotor Bearing (2)	2131-97		16	Hammer Case	
◆◆	4	Vane Packet (set of 6 Vanes) . .	2131-42A-6			Bushing	2131A-941
	5	Rotor	2131-53		17	Grease Fitting	D0F9-879
◆	6	Rear Rotor Bearing Retainer . .	2131-6	#◆◆+	18	Hammer Case Gasket	SN2131-36
	6A	Silencer	2131QT-311		19	Housing Assembly	
#◆◆	7	Motor Gasket	2131-283			(includes illustrated items	
	8	Anvil Assembly	231C-A626			7, 20, 21, 28 and 31)	AW5000-D40
◆◆	9	Socket Retainer	231-425A		20	Nameplate (2)	AW5000-301
◆◆	10	Socket Retainer O-ring .	R1A-159		21	Warning Label	WARNING-2-99
+	11	Hammer Case Screw (4)	2131-638				
		Hammer Frame Assembly	2131-A703				
	12	Hammer Frame	2131-703				
	13	Hammer Pin (2)	2131-704				

- ◆ Indicates Tune-up Kit part.
- +- # Indicates Seal Kit part.
- To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a Bullet (•) for every four tools in service.

MAINTENANCE INSTRUCTIONS
SECTION D'ENTRETIEN
WARTUNG
SEZIONE DI MANUTENZIONE
INSTRUCCIONES DE MANTENIMIENTO
ONDERHOUD

PART NUMBER FOR ORDERING
REFERENCE POUR COMMANDE DE LA PIECE
BESTELNUMBER
NUMERO DEL PEZZO PER L'ORDINAZIONE
SIMBOLO DE LA PIEZA PARA PEDIDOS
BESTELNUMMERS



	22	Inlet Bushing Assembly	2131-A565		34	Power Management Assembly	2131-A249
◆	23	Inlet Bushing		#◆	35	Power Management	
		Screen	5RA-61			Dial Seal	PS3-42
	24	Inlet Retainer Clip	2131-57		36	Inlet Clip Removal Tool	2131-322
◆	25	Inlet Parts Kit	2131-K303	*		Seal Kit (includes illustrated	
	25A	Washer	-----			items 7, 18, 25B, 27, 29,	
#	25B	Inlet Bushing Seal . . .	-----			30 and 35)	AW5000-K36
	25C	Tilt Valve Spring	-----	*		Tune-up Kit (includes	
	25D	Tilt Valve	-----			illustrated items 3, 4, 6, 7,	
	25E	Tilt Valve Seat	-----			9, 10, 18, 23, 25, 27, 29,	
	25F	Tilt Valve Seat				30 and 35)	AW5000-TK2
		Support	-----	*		Hammer Kit (includes	
	25G	Tilt Valve Seat Retainer	-----			illustrated items 11 [4],	
•	26	Trigger Assembly	2131-A93			14 [2], 18, and Anvil	
#◆	27	Trigger O-ring	-----			Assembly part	
	28	Reverse Valve Assembly	2131-A329			number 231C-A626)	AW5000-THK1
#◆	29	Reverse Valve O-ring (top)	-----				
#◆	30	Reverse Valve O-ring					
		(bottom) (blue)	-----				
	31	Button Kit	SN2131-K75				
	32	Forward Button	-----				
	33	Reverse Button	-----				

- * Not illustrated.
- ◆ Indicates Tune-up Kit part.
- # Indicates Seal Kit part.
- To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a Bullet (•) for every four tools in service.