

MB150UC Ultimate Cart

ASSEMBLY INSTRUCTIONS

- Step 1 Place the Locking Top and Drawer Unit (#1) on its back. Carefully open the Locking Top and lay it back against the ground.
- Step 2 Slide chrome legs (#2) into square holes in corners of Locking Top (#1) until bolt holes are aligned at top of legs.
- Step 3 Determine on which side of the cart the handle will be mounted. Then, insert two long bolts (#7) with two flat washers (#10) into the aligned holes in handle, locking top and legs. Fasten nuts (#9) using flat washers (#10) and lock washers (#11). Repeat this procedure for other corners using short bolts (#8).
- Step 4 Slide bottom tray (#15) onto legs and fasten as in Step 3.
- **Step 5** Insert casters (#3, #4) into the hole of plastic inserts (#5).
 - NOTE: Insert the two locking wheels (#3) at the same end of the cart.
- Step 6 Return cart to upright position.

No

Step 7 Using the screws (#16) provided, install drawer handles by aligning pre-drilled holes in drawers with slots in handle. Tighten all screws securely.

PARTS LIST

Dart

Item	Part	No.	
No.	No.	Req'd	Description
2	RSSC7L	2	Extra Long Chrome Leg/ea.
3	RS5LC	2	Locking Caster/ea.
4	RS5NLC	2	Non-Locking Caster/ea.
5	SCPP1	1	Set of 4 Plastic Inserts
6	RS150UCBK	1	Bolt Kit (Incl. #7, 8, 9, 10, 11, 16)
12	MBD150UCB-1	1	2-1/4" Replacement Drawer #1* (Red)
	MBD150UCB-1B	K	2-1/4" Replacement Drawer #1* (Black)
	MBD150UCB-1B	L	2-1/4" Replacement Drawer #1* (Blue)
	MBD150UCB-1Y	E	2-1/4" Replacement Drawer #1* (Yellow)
13	MBD150UCB-2	1	3" Replacement Drawer #2* (Red)
	MBD150UCB-2B	K	3" Replacement Drawer #2* (Black)
	MBD150UCB-2B	L	3" Replacement Drawer #2* (Blue)
	MBD150UCB-2Y	E	3" Replacement Drawer #2* (Yellow)
14	MBD150UCB-3	1	4-1/2" Replacement Drawer #3* (Red)
	MBD150UCB-3B	K	4-1/2" Replacement Drawer #3* (Black)
	MBD150UCB-3B	L	4-1/2" Replacement Drawer #3* (Blue)
	MBD150UCB-3Y	E	4-1/2" Replacement Drawer #3* (Yellow)
15	RS8007	1	Replacement Tray (Red)
	RS8007BK		Replacement Tray (Black)
	RS8007BL3		Replacement Tray (Blue)
	RS8007Y		Replacement Tray (Yellow)
16	RS150UCTA	2	Replacement Tray Assembly (Red)
	RS150UCTABK		Replacement Tray Assembly (Black)
	RS150UCTABL		Replacement Tray Assembly (Blue)
	RS150UCTAYE		Replacement Tray Assembly (Yellow)


Also Available:


RS8006HDL Drawer Handle (for Red, Black or Blue Cart)
RS8006HDLB Black Drawer Handle for Yellow Cart
RS8008LK Lock with Two Keys
RSRBSLIDEC2 Clip-On Roller Bearing Slides (One Pair)
RS150UCSD Safety Device
MB150UC

Tools Needed for Assembly:



Bolt Kit (#6) included for attaching legs and tray to MB150UC cart:





RS150UCSD Rev. 01/09/08

OPERATION OF SAFETY DEVICE

When the lid is fully opened, the safety device will automatically engage to prevent accidental closing. To disengage safety device, first ensure both folding side step trays are completely stowed inside box and all drawers are completely closed. Then, push the bottom portion of the device until it aligns with the open slot and slightly close the lid. Now, once hands and objects are cleared, the lid can be lowered to its fully closed and locked position.

NOTE: Do not attempt to close the box lid without depressing the safety device. Permanent damage to the lid will result!