

## **ASSEMBLY INSTRUCTIONS**

To simplify the assembly process, finger tighten all bolts until all bolts are in place. Once all bolts are in place, you can then final tighten.

- 1. Carefully lay bottom tray of utility cart on a clean work surface.
- 2. Take four legs with bumpers and bolt them to the bottom tray using the Torx bolts (A). Legs are labeled BL(back left), BR(back right), FL( front left) and FR(front right).
- 3. <u>If you do not have an add-on drawer unit</u> (MB89UCAD33, MB89UCAD36, or MB89UCAD6) proceed with bolting top tray in place and finger tighten all bolts. Remove the tie straps from legs and bumpers. Attach torx bolts to center holes of legs using spring washers, flat washers, and nuts.

If you have an add-on drawer unit (MB89UCAD33, MB89UCAD36, or MB89UCAD6), do not install the top front bolt on the FL and FR legs. Leave the side bolts on the FL and FR legs loose. Remove the tie straps from legs and bumpers. The next step is mount the prybar holders which are labeled left and right. Mount the left prybar holder to the inside of the left legs using the holes near the center of the legs. Mount the right prybar holder to the inside of the right legs using the holes near the center of the legs. Secure using Torx bolts, flat washers, spring washers, and hex nuts; this hardware comes with the drawer unit along with a separate assembly sheet. Remove the keys from the drawer unit. The drawer unit will now slide in the front of the cart and rest on the prybar holders. Align holes in top of drawer unit with holes in top tray and secure using hex bolts and flat washers. Now tighten side bolts and front bolts of the legs.

4. Determine which side the cart handle will be on. Remove the lower side bolts from the front and back legs. Mount handle and tighten bolts. You can now final tighten all bolts.

WARNING: Make sure the lid is locked.


5. Using handle, roll cart forward onto the opposite side. Mount casters using hex bolts, spring washers, and flat washers.

**NOTE:** It is recommended that the locking casters go onto the same side as the handle.

- 6. Roll cart upright onto casters.
- 7. Install divider in bottom tray if desired.



## MB89UCL, -BK, -BL, -YE, -LG, -OR, -PP, -GRAY Utility Cart w/ Locking Lid



## PARTS LIST

| Item | Part           |  |        | Item | Part          |  |     |
|------|----------------|--|--------|------|---------------|--|-----|
| No.  | No.            | Description                                  | Qty    | No.  | No.           | Description                                  | Qty |
| 1    | MB89UCLLID     | Red Top Tray w/ Locking Lid                  | 1      |      | RS89UCLGBPP   | Purple Leg/each for front right or back left |     |
|      | MB89UCLLIDBK   | Black Top Tray w/ Locking Lid                |        |      | RS89UCLGBGRAY | Gray Leg/each for front right or back left   |     |
|      | MB89UCLLIDBL   | Blue Top Tray w/ Locking Lid                 |        | 5    | RS89UCNLC     | Non-Locking Caster/each                      | 2   |
|      | MB89UCLLIDYE   | Yellow Top Tray w/ Locking Lid               |        | 6    | RS89SCD       | SprayCan Divider-Red                         | 1   |
|      | MB89UCLLIDLG   | Lime Green Top Tray w/ Locking Lid           |        |      | RS89SCDBK     | SprayCan Divider-Black                       |     |
|      | MB89UCLLIDOR   | Orange Top Tray w/ Locking Lid               |        |      | RS89SCDBL     | SprayCan Divider-Blue                        |     |
|      | MB89UCLLIDPP   | Purple Top Tray w/ Locking Lid               |        |      | RS89SCDYE     | SprayCan Divider-Yellow                      |     |
|      | MB89UCLLIDGRAY | Gray Top Tray w/ Locking Lid                 |        |      | RS89SCDLG     | SprayCan Divider-Lime Green                  |     |
| 3    | RS89UCLB       | Leg Bumpers (set of 4)                       | 1      |      | RS89SCDOR     | SprayCan Divider-Orange                      |     |
| 4A   | RS89UCLGA      | Red Leg/each for front left or back right    | 2      |      | RS89SCDPP     | SprayCan Divider-Purple                      |     |
|      | RS89UCLGABK    | Black Leg/each for front left or back right  |        |      | RS89SCDGRAY   | SprayCan Divider-Gray                        |     |
|      | RS89UCLGABL    | Blue Leg/each for front left or back right   |        | 8    | MB89UCBS      | Bottom Tray-Red                              | 1   |
|      | RS89UCLGAYE    | Yellow Leg/each for front left or back right |        |      | MB89UCBSBK    | Bottom Tray-Black                            |     |
|      | RS89UCLGALG    | Lime Green Leg/each for front left or back   | right  |      | MB89UCBSBL    | Bottom Tray-Blue                             |     |
|      | RS89UCLGAOR    | Orange Leg/each for front left or back righ  | t      |      | MB89UCBSYE    | Bottom Tray-Yellow                           |     |
|      | RS89UCLGAPP    | Purple Leg/each for front left or back right |        |      | MB89UCBSLG    | Bottom Tray-Lime Green                       |     |
|      | RS89UCLGAGRAY  | Gray Leg/each for front left or back right   |        |      | MB89UCBSOR    | Bottom Tray-Orange                           |     |
| 4B   | RS89UCLGB      | Red Leg/each for front right or back left    | 2      |      | MB89UCBSPP    | Bottom Tray-Purple                           |     |
|      | RS89UCLGBBK    | Black Leg/each for front right or back left  |        |      | MB89UCBSGRAY  | Bottom Tray-Gray                             |     |
|      | RS89UCLGBBL    | Blue Leg/each for front right or back left   |        | 9    | RS89UCLC      | Locking Caster/each                          | 2   |
|      | RS89UCLGBYE    | Yellow Leg/each for front right or back left |        | 12   | RS89UCPH      | Push Handle                                  | 1   |
|      | RS89UCLGBLG    | Lime Green Leg/each for front right or bac   | k left | 14   | RS89LK        | Chrome Lock w/keys                           | 1   |
|      | RS89UCLGBOR    | Orange Leg/each for front right or back lef  | ť      |      | RS89LKBK      | Black Lock w/ keys                           |     |
|      |                |  |        | 15   | RS89UCLGP     | Gas Piston/each                              | 2   |
|      |                |  |        |      |               |  |     |

## HARDWARE SPECIFICATIONS

| А | Torx | Bolts | (M8 x | 18) |
|---|------|-------|-------|-----|
|---|------|-------|-------|-----|

- B Hex Bolts (M8 x 16)
- C Flat Washers
- D Spring WashersE Nut

Available as:

RS195UCBK

32 Torx Bolts (M8 x 18)

40 Pcs.

16 Pcs.

24 Pcs.

24 Pcs.

8 Pcs.

RS89UCCB Caster Bolt Kit (16 each of B, C, & D)

RS89LBK Leg Bolt Kit (8 each of Torx Bolts [M8 x 18], Flat Washers, Spring Washers, Nuts) Replacement liners available as RS89UCLK, liner set for Top and Bottom Trays

D

Replacement MAC TOOLS logo decal available as RS89MACLOGO (white) or as RS89MACLOGOBK (black)